

Ezy-Mount® Auxiliary Light Bracket Instructions

P/N F650/800GS (Model Year 2008–09)

(Recommended full-time use only with (35W) Series Lights)

55w PIAA 1100, 004, 1400, P1000, 510, or Hella Optilux 1500 Series Lights recommended only for intermittent use.

CAUTION: Disconnect negative battery lead before light kit harness and switch installation.

READ INSTRUCTIONS THOROUGHLY, INVENTORY HARDWARE AND FAMILIARIZE YOURSELF WITHEACH PIECE & IT'S ASSOCIATED USE BEFORE BEGINNING INSTALLATION.....

NOTE: Be sure to re-apply medium grade loctite to the fender screw threads before re-installing each screw.

- Step 1** Front fender extension is secured with 4 ea 10/32 Torx Head Screws (2 ea side). Remove 2 screws from left or right side, re-install screws thru bracket mount holes, securing light bracket for that side. Move to other side and repeat. See pic below for correct bracket orientation/placement.
- Step 2** Place re-inforcement 'Cross-Brace', between left and right side brackets, and secure with one 8/32x1/2 Torx screw, flat & lock on each side.
- Step 3** Securing PIAA® lights to **Ezy-Mount®** brackets. Lights may be mounted above or below platform, depending upon your light style and needs. Fasten lights to brackets with supplied hardware, as described in the parts list. Using machine Sym screws, (with black shoulder washer adapter for PowerSports kits only), mount PIAA base bracket to **Ezy-Mount®** bracket placing shoulder washer adapter in 10mm hole, with machine sym screw. (Adapter washer centers screw in 10mm hole, keeping light base centered.)
- Step 4** Route light pigtails back to harness under fender. Use included tie-wraps to secure wires as needed. Various holes provided in brackets for this purpose.

SAFETY: Use lights only as conditions require and adjust beam alignment, so as not to create a safety hazard to oncoming vehicles. Ride safe & smart.

Parts List:	1)	1	Left Powder-coated	(w/ Pressed Stainless Pemnuts)
	2)	1	Right Powder-coated	(w/ Pressed Stainless Pemnuts)
	3)	1	Center Powder-coated re-inforcement 'Cross-Brace'	(w/Pressed Stainless Pemnuts)
	4)	4	Stainless SEM Screw, 10/32x1/2"	(Use w/1100 Lights /1 per side, P1000 Lights /2 Per Side)
	5)	4	Stainless SEM Screw, 6/32x3/8"	(Use w/ PIAA 004, 1400 & Hella Optilux 1500's / 4 Per Side)
	6)	2	Stainless Torx Head SEM Screw, 8/32x1/2"	(Use to secure 'Cross-Brace' between left/right light brackets)
	7)	2	#8 Flat Washer, SS	
	8)	2	#8 Lock Washer, SS	
	9)	4	#10 Nut Cap, Black	(Cap Nuts Used to dress top of bracket / hide h/w protrusions from view)
	10)	4	#6 Nut Cap, Black	
	11)	2	10mm Nut Cap, Black	(Use with 510 Series Lights)
	12)	2	Shoulder Adapter Washer, Black Nylon	(Use with PowerSports Kits only)
	13)	4	Tie Wraps, Black 3.75"	

***** CAUTION *****

The **Ezy-Mount®** kit is designed for use only with PIAA® or Hella Optilux® Series lights as indicated for this kit. Use of light kits not referenced in these instructions, especially larger heavier light bodies is not recommended and may interfere with the safe operation of your motorcycle.



Ezy-Mount®
Products

© 2009

3407 Aries Drive, Garland, TX. 75044 · 866-287-5871 · www.ezymount.com



Made in the USA



