

Ezy-Mount® Auxiliary Light Mounting Kit

P/N R1200RT

For ESA Model Only - Do Not Use with Lowered Suspension Option

(Use only with PIAA® 1100PX & 004 Series)

READ INSTRUCTIONS THOROUGHLY, INVENTORY HARDWARE AND FAMILIARIZE YOURSELF WITHEACH PIECE & IT'S ASSOCIATED USE BEFORE BEGINNING INSTALLATION.....

CAUTION: DO NOT USE PIAA® kit adhesive fasteners. Do Not Use With PowerSports Lights.

Note: It is recommended that you remove side panels to drill holes, before mounting brackets. Only 1 hole per side required. Location described below (Step 2).

CAUTION: Carefully route all wiring and placement of relay, to minimize interference with normal maintenance. Routing of wiring harness over top of gas tank will delay removal of tank for maintenance. Alternate routing to lights is suggested.

- Step 1** Locate 'mold circle' indentation on each panel. (Pic 1) With fairing panel mounted on bike, this indentation is center, at rear inside panel edge, and faces inside. Install bracket as shown in (Pic 2), align bottom bracket hole over indentation and mark for hole. Remove brackets at this time.
- Step 2** Remove fairing body side panels. Four screws per side required for removal, see owners manual. Drill a 3/8" hole at mark.
- Step 3** As required, re-install fairing body side panels. Do not re-install the top factory inner panel Torx Screw yet, as you will re-use this screw to secure the top light bracket mounting hole to the fairing panel.
- Step 4** Using 10/32x1/2 screws from H/W package, secure lights to *Ezy-Mount®* brackets. (See Pics 3 & 4) Right side bracket is stamped 'EZY-MOUNT'. Due to close proximity of the light body to fairing side panel, access to the vertical adjustment screw on the panel side of the light will not be possible after installation. To prepare for this, before installing bracket/light assy to panel, make sure this screw is tightened so that you can barely move the light body. After bracket is installed, final vertical adjustment can be secured with the inside screw. Torque on this screw is adequate to hold vertical adjustment, and the screw that faces the panel will not come loose.
- Step 5** Insert well nut into previously drilled 3/8" hole. Place bracket assy against fairing, aligning top hole with the top fairing mounting position, re-install the factory Torx screw at this location, adjust so that screw touches bottom of mounting slot. Now install the second supplied SS 10/32 x 5/8 Torx screw thru the lower bracket mounting hole to the well nut. **With constant pressure on the screw**, tighten securely. Constant pressure ensures that the rear expandable section of the well nut captures the back of the plastic inner panel as you tighten the screw. Future removal of fairing panels is now possible with light assys installed (utilizing the bottom bracket mounting screw), thus re-alignment of lights is not required after normal maintenance.

Congratulations you are done... ! Connect lights to harness, adjust vertical beam alignment & R I D E !

SAFETY: Use lights only as conditions require & adjust beam alignment, so as not to create a safety hazard to oncoming vehicles. Please ride safe & smart.

Parts List:	1)	2	Ezy-Mount® Brackets (left & right)	(Black Powdercoat with #6 & #10 SS Pemnuts)
	2)	2	SS SEM Screw (Torx) 10/32x5/8	(light bracket mounting screw)
	3)	2	SS SEM Screw 10/32x1/2	(for use with 1100 Series Lights)
	4)	4	SS SEM Screw 6/32x3/8	(for use with 004 Series Lights)
	5)	2	Tie Wrap, 3.7" Blk	
	6)	2	Well-Nut	

Tool List : Phillips Screwdriver, T25 Torx Wrench (BMW Tool Kit)

Thank you for purchasing our product. Please feel free to provide comments about your experience with the installation of the kit. Please Email comments to me at info@ezymount.com, or forward by mail to address listed below. Thank You ☺



► **Refund Policy:** *Ezy-Mount*® Products will refund the purchase price and applicable taxes, if any, for items that are found to be defective in material or workmanship. Items must be returned, **unused, in their original packing along with Original invoice.** You must contact the sales office for a Return Material Authorization (RMA) number before returning any items. The RMA number must appear on the outer packaging of the returned item.

► **Liability:** Motorcycle damage due to modifications, improper installation, road hazards or accident, are not covered. Seller's only obligation shall be to replace product proved to be defective. Seller shall not be liable for any injury, loss or damage, direct or consequential, arising out of improper installation, or inability to use product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability, whatsoever, in connection therewith. Installation by user, or his/her appointed installer constitutes acceptance of these conditions of use, and of all risk and liability as stated above.

***** Caution *****

This *Ezy-Mount*® bracket kit is designed for use only with **PIAA**® Automotive 1100PX, 004X & 1100PX Series lights. Use of other lights with this kit is not recommended, as you may encounter potentially damaging contact with fender, forks and/or light bodies. Use of this kit on the **conventional, or lowered suspension** model may result in light body contact with front fender and is not recommended.



Pic 1



Pic 2



Pic 3



Pic 4

**Ezy-Mount®
Products**

© 2006-2009

3407 Aries Drive, Garland, TX. 75044 · 866-287-5871 · www.ezymount.com



Made in the USA

